


# booi workstation


BO S BASE + BO S CHAIR + LM

## installation manual




**bejot:**


1




2




3



4






5




## PEOPLE




## ADDITIONAL TOOLS




## ATTACHED




x4




x8




x1





1




2





# 3




# 4





5





6





# 7



# 8




9






10



11



**Bejot Sp. z o. o.**

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: [biuro@bejot.eu](mailto:biuro@bejot.eu)

[www.bejot.eu](http://www.bejot.eu)

edition 10/2021