





quadra module

installation manual








bejot:




connectors




additional tools




1





2




3




4





middle





corner




5




6




7




8




9




10





11






12



13



Disassembly



Bejot Sp. z o. o.

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: biuro@bejot.eu

www.bejot.eu

edition 01/2022