


# orte tables


OTW 4L AA, OTW 4L AH, OT 4L, OT 4L A, OT 4L AA, OT 2Q

## installation manual




**bejot:**

1




2



x2

3





x4


## PEOPLE




## ADDITIONAL TOOLS




## ATTACHED




x8




1




II




2




3




4








5



6



7



**Bejot Sp. z o. o.**

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: [biuro@bejot.eu](mailto:biuro@bejot.eu)

[www.bejot.eu](http://www.bejot.eu)

edition 01/2022