


# alberi wall


ALPSC 1580 W1, ALPSC 1110 W1, ALPSC 1580 W2, ALPSC 1110 W2,  
ALPSC 1580 W3, ALPSC 1110 W3

## installation manual






**bejot:**

people




additional tools




parts

1



2







3



4





attached






\* - not added for assembly,  
parts suitable for the ground






1






2




3




4







5



6





**Bejot Sp. z o. o.**

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: [biuro@bejot.eu](mailto:biuro@bejot.eu)

[www.bejot.eu](http://www.bejot.eu)

edition 02/2022