


orte folding table


OT 2L T

installation manual




bejot:

1




2




x2


PEOPLE




ADDITIONAL TOOLS




ATTACHED




x4




1




2






II





III




3




4




1



II



III



Bejot Sp. z o. o.

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: biuro@bejot.eu

www.bejot.eu

edition 02/2022